verizon

Get to Know Your Phone

Para la versión en español, visite
verizonwireless.com/support

DROID TURBO 2 by motorola

About Your Phone

- Nano SIM & MicroSD Card Tray
- Headset Jack
- Front Camera
- Camera Flash
- Power/Lock Button
  - Press: Screen On/Off
  - Hold: Phone On/Off
- Earpiece
- Volume Buttons
- Audio Ports
- USB/Charger Port

- Back Camera
- Camera Flash
- NFC Touchpoint
- Microphone

NOTE: Devices and software are constantly evolving—the screen images and icons you see here are for reference only.

Setting Up Your Phone

Your phone comes with the SIM card pre-installed.

Optional: Insert a microSD Card

1. With the phone facing up, insert the tool that comes with your phone into the small hole on the card tray and pop out the tray.

2. Insert the microSD card into the tray with the gold contacts facing up.

NOTE: The microSD card is sold separately.

3. Carefully insert the tray back into the phone.

Charge Your Phone

Before turning on your phone, charge it fully.

1. Insert the small end of the USB cable into the USB/charger port.
2. Insert the other end into the power adapter, and plug the power adapter into an electrical outlet.

WARNING! Please use only an approved charging accessory to charge your phone. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your phone and void the warranty.

SAR ✓ This product meets the applicable national or international RF exposure guidance (SAR guideline) when used normally against your head or, when worn or carried, at a distance of 1.5 cm from the body. The SAR guideline includes a considerable safety margin designed to assure the safety of all persons, regardless of age and health.

Using Your Phone

Turning Your Phone On/Off

To turn your phone on, press and hold the **Power/Lock** button until the screen turns on.

To turn your phone off, press and hold the **Power/Lock** button and then tap **Power off**.

Locking/Unlocking the Screen

To turn on your screen, press the **Power/Lock** button. Then drag the lock icon 🔒 up to unlock it.

Swipe right to make a call.

Drag up to unlock your screen.

Swipe left to open the camera.

To turn off your screen and prevent accidental key presses, press the **Power/Lock** button. Your phone will also lock automatically if you don't use it for a while.

Home Screen

Swipe down with one finger for notifications, or with two fingers for profiles and settings.

Search by typing, or tap 🎤 for a voice search.

Touch and hold an empty spot to add widgets, change wallpaper, or adjust settings.

Tap Apps (⦂⦂⦂) to see all your apps.

◁ **Back**
◯ **Home**
☐ **Overview**

Shattershield™

Your phone display is guaranteed not to crack or shatter. But be careful—you still need to guard against scratches and other minor damage.

Find out more about this innovative display and how to care for it by visiting **motorola.com/shattershield**.

Volume and Interruptions

Press the side volume buttons up or down to select a ringer volume from high to vibrate 〈□〉.

Tap an option under the volume slider to select which interruptions and alarms you want to receive: **All**, **Priority**, or **None**.

Tap to change interruption settings.

Set volume by dragging the slider or pressing the side volume buttons.

Tap to switch between vibrate and ring.

Advanced Calling

You can make High-Definition Voice and Video Calls, and surf the web while you talk on the phone, when you add Advanced Calling to your line. Visit **verizonwireless.com/AdvancedCalling** to learn how.

Copying Content from Your Old Phone

For help transferring contacts, photos, and other content from your old phone, visit **verizonwireless.com/cloud**.

Learning More

The **Help** app gives you tips, videos, and other information on how to use your phone, including:

📞 Making Calls

📟 Voice Mail

💬 Sending Texts

▶ Getting Apps

📷 Taking Photos

⚙ Accessibility Settings

From your computer, visit **verizonwireless.com/support**.

Download a User Guide from **verizonwireless.com/support**, or call **(800) 734-5870** to order a copy.

Managing Your Account

My Verizon Mobile App

Manage your account, track your usage, edit account information, pay your bill, and more.

International Travel

For features and rates when traveling outside the US, visit **verizonwireless.com/international**.

Customer Service

Call **(800) 922-0204**.
Follow us **@VZWSupport**.

Additional Information

Your Wireless Device and Third Party Services
Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this wireless device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this wireless device or any non-Verizon Wireless applications, services and products, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use, and privacy policies shall apply. Please review carefully all applicable terms and conditions and policies prior to using this wireless device and any associated application, product or service.

Hearing Aid Compatibility Information
This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

Copyright & Trademarks
MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. Android, Google and other trademarks are owned by Google Inc. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution License. DROID is a trademark of Lucasfilm Ltd. and its related companies. Used under license. All other product or service names are the property of their respective owners.

Product ID: Droid Turbo 2 by Motorola (Model XT1585)
Manual Number: 68017992001-A